

User's Manual

Advanced Dual-Laser
Omnidirectional Vertical Scanner



Revision History

Changes to the original manual are listed below:

Version	Date	Description of Version
1.0	2012/11/01	Initial release
1.1	2020/3/25	Cable voltage corrected
1.2	2022/2/15	DOF/Dimension updated

Important Notice

No warranty of any kind is made in regard to this material, including, but not limited to, implied warranties of merchantability or fitness for a particular purpose. We are not liable for any errors contained herein or incidental or consequential damages in connection with furnishing, performance or use of this material.

No part of this document may be reproduced, transmitted, stored in a retrieval system, transcribed, or translated into any language or computer language in any form or by any means electronic, mechanical, magnetic, optical, chemical, manual or otherwise, without express written consent and authorization.

We reserve the right to make changes in product design without reservation and without notification. The material in this guide is for information only and is subject to change without notice. For the latest revision please contact your distributor.

All trademarks mentioned herein, registered or otherwise, are the properties of their various respective owners.

Copyright © 2022. All rights reserved.

This manual is in A5 format. Please check your printer setting before printing it out.

Laser Safety

The Advanced Compact Dual-Laser Omnidirectional Vertical Scanner complies with safety standard IEC 60825 for a Class I laser product. It also complies with CDRH as applicable to a Class IIa laser product. Avoid long term staring into direct laser light.

Radiant Energy: The Dual-Laser Omnidirectional Vertical Scanner uses two low-power visible laser diodes operating at 650nm in an opto-mechanical scanner resulting in less than 3.9 μ W radiated power as observed through a 7mm aperture and averaged over 10 seconds.

Do not attempt to remove the protective housing of the scanner, as unscanned laser light with a peak output up to 0.8mW would be accessible inside.

Laser Light Viewing: The scan window is the only aperture through which laser light may be observed from this product. A failure of the scanner motor, while the laser diode continues to emit a laser beam, may cause emission levels to exceed those for safe operation. The scanner has safeguards to prevent this occurrence. If, however, a stationary laser beam is emitted, the failing scanner should be disconnected from its power source immediately.

Adjustments: Do not attempt any adjustments or alteration of this product. Do not remove the protective housing of the scanner. There are no user-serviceable parts inside.

Caution: Use of controls or adjustments or performance of procedures other than those specified herein may result in hazardous laser light exposure.

Optical: The use of optical instruments with this product will increase the eye hazard. Optical instruments include binoculars, magnifying glasses, and microscopes but do not include normal eye glasses worn by the user.

For CE-Countries

This scanner is in conformity with CE standards. Please note that an approved, CE-marked power supply unit should be used in order to maintain CE conformance.

Table of Contents

Important Notice.....	ii
Introduction	1
Unpacking.....	2
Finding Your Way Around.....	3
Outline.....	3
Caution Label	5
Cable Installation.....	5
Connection.....	6
Power	6
Connecting to the Host	6
Turn on the host system.....	7
Interface Cable Replacement	10
Mounting.....	11
Diagrams for Mounting	11
Mounting Plate Installation.....	12
Auxiliary Handheld Scanner Connection (Optional).....	14
Back Mounting	15
Site Preparation.....	16
Configuring the Scanner.....	16
Scan Test.....	16
Set Up.....	17
Controlling the Scanner from POS System	18
Setting EAS System	18
Operation	20
LED Indications.....	20
Sound Indications.....	20
Tone and Volume Adjustment.....	21
Sleep Mode	22
How to Scan	23
Scan Volume.....	23
Scanning Mode.....	24
Maintaining the Scanner.....	25
Trouble Shooting	26
Specification.....	27
Dimension	28
Decode Zone	30
Pin Assignment.....	32
Device.....	32
Interface Cable	33

Introduction

The Advanced Compact Dual-Laser Omnidirectional Vertical Scanner is a vertical scanner empowered with dual-laser technology, enabling 40 scan lines at a rate of 3600 scans per second. Along with the proprietary hardware decoding technology, the scanner guarantees unbeatable decoding speed and accuracy, the best choice for high-traffic applications, including hypermarket, healthcare, warehouse management and manufacturing process control.

When working in field, the scanner has a two-color LED to provide immediate visual feedback. It also has two advanced touch control sensors in the front, allowing beeping tone and volume adjustment.

With a built-in EAS antenna, field-replaceable interface cable and an additional handheld scanner port, the Advanced Compact Dual-Laser Omnidirectional Vertical Scanner is the ultimate device for users demanding functionality and quality.

Key Features:

- Unique dual-laser technology
- Proprietary hardware decoding technology
- Large scan field
- Barcode stitching capable
- Instant “object-fly-by” automatic wake-up
- Easy on-site configuration
- Touch control sensors for sound indication adjustment

Unpacking

The omnidirectional scanner package contains:

Advanced compact dual-laser omnidirectional vertical scanner



Interface cable (This cable is usually, but not always, supplied. Model depends on customer needs.)



9V power adapter
(Model depends on electrical requirements of your geographic location)



User's manual & programming guide in CD-ROM



- Please leave this user's manual within easy access for persons using the scanner.
- If any contents are damaged or missing, please contact your dealer immediately.

Finding Your Way Around

Outline




Figure 1: Outline




Figure 2: Connector Panel

Description	Function
Scan Window	Read barcodes
Speaker Exit	For beep tone indication
LED Indicator	Reading status indication
Tone Adjustment	Adjusting sound indication tone
Volume Adjustment	Adjusting sound indication volume
Back Mounting Holes	For permanent fixture (optional)
Cable Release Hole	Connecting interface cable
Interface Cable Connection	For interface communication connection to the host
AUX Connection	Connecting an auxiliary scanner (optional)
EAS Connection	Electronic Article Surveillance connection (optional)

Caution Label




Figure 3: Label

Cable Installation

The scanner is to be connected to a host (e.g. POS). The use of external power is determined by your host but it is usually recommended. The scanner also supports an auxiliary scanner and EAS application. The figure below gives you an overview of the cable installation.




Figure 4: Cable Installation

Connection

Power

The scanner requires a minimum of 450mA at 9 V DC power. The interface cable that comes with the scanner supports both direct power (where the scanner takes power from the host machine) and external power (that's what the supplied power adapter is for). A sufficiently robust POS system can support a scanner successfully without external power; a POS system with a barely adequate power supply may produce erratic performance (either of the POS system itself, or of the scanner, or both) when a scanner is attached. Unless you are sure your POS system can handle the load, it is recommended that you use the supplied power adapter. When an external adapter is connected, the scanner does not take power from the host.

The scanner turns on when power is supplied, and turns off when power is removed. There is no on/off switch on the scanner itself. Use only an AC/DC power adapter approved for the scanner. Use of other power supplies may cause damage to the product, and void the factory warranty.

Follow the steps below when you need an external power connection to the scanner (Refer to Figure 4):

1. Connect the interface cable to the bottom of the scanner.
2. Connect the other end of the interface cable to the host (refer to your host manual to locate the correct port).
3. Plug the power supply into the power jack on the interface cable.
4. Plug the other end of the power supply into an AC outlet.

Connecting to the Host

The interface cable comes with different host-end connectors, depending on the host. Follow the steps below to connect the interface cable to the host.

1. Make sure that the power of the host system is off.
2. Plug the host end of the interface cable to the appropriate connector on the host system.
3. For those cases where external power is used, plug the external AC power adapter into the jack on the interface cable.

Turn on the host system.

Connecting Auxiliary Scanner

To connect an auxiliary scanner to the AUX port:

1. Connect the auxiliary interface cable to the auxiliary port of the scanner.
2. Connect the other end of the cable to the auxiliary scanner.
3. Connect the power supply if necessary.
4. Use the programming barcodes to activate the auxiliary port of the vertical scanner and set up its data transmission mode. (Refer to its separate Programming Guide.)

Connecting EAS

The scanner's integrated EAS deactivation antenna requires an EAS host cable.

1. Make sure that the power of the EAS system is off.
2. Plug the cable to the appropriate connectors on the scanner and the EAS system as illustrated in Figure 4.
3. Turn on the EAS system.

Verifying Scanner Operation

Before mounting your scanner, please follow the procedure below to verify scanning operation.

1. Take a stick to poke in the hole at the back of the scanner to remove the mounting plate.




Figure 5: Mounting Plate Removal

2. Insert the 10-pin modular plug of the interface cable into the “Host” connector at the back of the scanner until a firm click is heard.



Figure 6: Host Cable Connection

3. Insert the bracket on interface cable to the cable release hole of the mounting plate as shown. Make sure the flat side of the bracket goes in first




Figure 7: Cable Holder

4. Insert the latches of the mounting plate into the latch holes of the scanner.



Figure 8: Latches

5. Close the mounting plate as shown in the figure.



Figure 9: Put the mounting plate back

1. Plug the other end of the cable to the host.
2. Plug the power adapter into the jack on the interface cable.
3. Plug the AC end of the power adapter into an AC outlet. The scanner powers up, the speaker sounds four beeps and the LED indicator glows blue.
4. Present a known-good test barcode to the scanner. The scanner should issue a short beep and the LED should flash red momentarily.



- If the scanner is connected to a keyboard wedge for this test, it should read one barcode, beep, and the LED remain red. This is normal when the keyboard wedge is not connected to a live host terminal.
- The LED would flash red and read no barcode if the scanner is programmed in USB interface but not connected to a host device.
- If the scanner does not produce any beeps, or produces the wrong beeps, or the LED is not lit up, remove the power connection and refer to the section of Troubleshooting.

Interface Cable Replacement

The interface cable comes with different host-end connectors, and there are 5 standard types of interface connection that this device supports:

- Keyboard wedge
- RS-232 interface
- USB interface (supporting HID USB, virtual COM, OPOS USB)

The standard interface cable is attached to the scanner with a 10-pin modular connector. When properly seated, the connector is secured in the scanner bottom by a flexible retention tab. The cable is designed to be field replaceable. Replacement cables can be obtained from your authorized distributor.

To replace the cable, follow these steps.

1. Make sure that the power of your computer system is switched off. If a power adapter is used, disconnect it from the scanner cable.
2. Disconnect the old scanner cable from the computer system.
3. Use a stick to remove the mounting plate from the scanner.
4. Press down the small tab on the connector where the old cable is attached to the scanner and pull out the connector.
5. Insert the 10-pin modular plug of a new interface cable into the "Host" connector at the back of the scanner until it clicks.
6. Insert the connecting cable in the slot of the mounting plate.
7. Mate the scanner and the mounting plate, engaging the tab on the underside. Be careful not to pinch the cable.
8. Plug the new cable into the host.
9. If a power adapter is used, plug the power adapter into the jack on the interface cable.
10. Re-program the scanner interface setting with barcodes in the Programming Guide.

Mounting

After the scanner passes its verification test, you may proceed with mounting for permanent fixture.

The scanner should be installed in a location away from direct sunlight; high levels of ambient light reduce scanner effectiveness.

The two basic styles of mounting are

- a) with the included mounting plate, and
- b) with a custom bracket (not included) for back mounting.

If an auxiliary handheld scanner is to be attached, it must be properly connected as part of the mounting process.

Diagrams for Mounting

The device is reserved with 2 mounting holes at the back and 4 mounting holes at bottom. Refer to the figure below for detailed information.

Back View

Unit: mm (inch)




Figure 10: Diagrams for Mounting (Back)

Bottom View

Unit: mm (inch)




Figure 11: Diagrams for Mounting (Bottom)

Mounting Plate Installation

1. Position the mounting plate in the desired location and secure it in place.



Figure 12: Mounting Hole Positions

2. Insert the interface cable in the cable release hole of the mounting plate.



Figure 13: Position the interface cable

11. Insert the 10-pin modular plug of the interface cable into the “Host” connector at the back of the scanner until a firm click is heard.
12. Move the scanner into position on the mounting plate, engaging the tab on the underside. Be careful not to pinch the cable.



Figure 14: Slide the mounting plate into scanner

Auxiliary Handheld Scanner Connection (Optional)

The scanner supports the operation of an auxiliary handheld scanner, which may be connected via a 10-pin modular plug to the connector marked "AUX" at the back of the scanner.

1. Insert the 10-pin modular plug of scanner cable into the "Host" connector at the back of the scanner until a firm click is heard.
2. Take a knife to cut open the rectangular reserved hole.



Figure 15: Routing Hole for Handheld Scanner Cable

3. Route the auxiliary cable through the rectangular hole.
4. Insert the auxiliary cable connector into the 10-pin "AUX" jack until a firm click is heard.



Figure 16: Insert the scanner cable and the auxiliary Cable

5. Slide the mounting plate into the scanner. Be careful not to pinch any cables.



Figure 17: Cable installation completed

Back Mounting

If desired, the scanner may be mounted to your own custom bracket by using the threaded mounting holes at the back (See Figure 1). The mounting holes are threaded to accommodate M3 x 0.5 machine screws to a depth of 6.0 mm.

Make sure your bracket design allows for the exit of the interface cable. The supplied mounting plate protects the interface cable connection, but requires that the cable exits from the back of the unit.

Site Preparation

Configuring the Scanner

In certain cases no setup is required. The scanner is either pre-programmed to suit the situation, or it automatically detects and is ready to go. In other cases the scanner must be informed about what kind of system it is connected to. This can be done in a few moments using the programming barcodes in the separate Programming Guide.

The programming section may be used to set a number of parameters on the scanner: communication interface type, sleep mode timing, same-code delay time, barcode symbologies, and more advanced settings like setting headers and trailers.

The settings are to be stored in non-volatile memory and are preserved even when the scanner is powered down. Individual parameters may be set at any time without affecting the other parameters.

Scan Test

Follow the steps below to ensure that your scanner can work well with your host system.

1. With the scanner running (blue LED lights) and the host system on, try to scan several known-good barcodes.
2. Check the results on the POS screen. If the scanner is reading okay, it is likely that no further setup is necessary.
3. If the POS screen does not show the expected scans, go to the Set Up section below.

Set Up

When the scanner is powered on (blue LED lights), find the <Enter/Exit Programming Mode> barcode in the Programming Guide and present this barcode to the scanner. When the scanner gives two beeps (one low and one high) and the LED turns red, it means the scanner is in programming mode.

1. Decide which parameters are required and find their barcodes in the Programming Guide.
2. Cover unwanted codes with your hand and present the desired codes one by one to the scanner; the scanner beeps once as it accepts each code.
3. When done, again present the <Enter/Exit Programming Mode> barcode.
4. The scanner beeps twice of the same tone, and the LED returns to blue. It means the scanner has been programmed.
5. Test again with known-good barcodes. If results are good, you are done setting up. Otherwise, return to step 1 and try again.




Figure 15: Programming Procedure

Controlling the Scanner from POS System

The scanner can be controlled from the POS system via the RS-232C interface. Controlling can be accomplished by transmitting the following single byte commands to the scanner. The default settings of the commands are as follows:

ASCII Code	Function	Byte is Also Called:
0E Hex	enable (resumes disable)	Shift Out or <Ctrl-N>
0F Hex	disable	Shift In or <Ctrl-O>
05 Hex	power-up re-initialization	ENQ or <Ctrl-E>
12 Hex	sleep	DC2 <Ctrl-R>
14 Hex	wake up (resumes sleep)	DC4 <Ctrl-T>



When the scanner is disabled (unable to scan), the motor of the scanner will stay on until the scanner goes into sleep mode.

Setting EAS System

The scanner supports the use of an EAS antenna and can work simultaneously with an EAS system using the interlock feature. When enabled, users may scan and deactivate an item at the same time. To setup the scanner:

1. Scan the Enter/Exit Programming barcode to begin the setup.
2. Scan the setting barcodes to setup the scanner. Multiple setup barcodes can be scanned at this step.
3. Scan the Enter/Exit Programming barcode again when you are done to save the settings.



Enter/Exit Programming

Setting EAS Interlock

When enabled, the EAS tag is not de-activated until the associated barcode is decoded.



EAS Interlock Enable

When disabled (default), the EAS tag is de-activated independently of any barcode scanning.



EAS Interlock Enable (Default)

Setting EAS Active

Use this setting to set the polarity of the EAS allowing the scanner to send an EAS output after a good barcode read to deactivate a tag on the product.



EAS Active state = Active High



EAS Active state = Active Low (Default)

Setting EAS Timeout

Use this setting to set EAS Timeout. EAS output signal is held in its active state for a good read indication. To set the timeout:

1. Scan the Enter/Exit Programming barcode to begin the setup.
2. Scan 3 ASCII number barcodes (Please see Programming Guide) to set the time in millisecond. For example:
3.
 - 000:disable the feature
 - 001:10 msec
 - 002:20 msec
 - 250:2500 msec (2.5second)
4. Scan the Enter/Exit Programming barcode to save the settings.



Set EAS Timeout

EAS Pin-out

	Function	Color	Note
1	Ground	Red	
2	Antenna+	Orange	
3	Antenna-	Black	
4	EAS In	Green	
5	EAS Out	White	Open collector output
6	Shield	Purple	

Operation

LED Indications

Red and blue dual color LED signals indicate the operational status of the scanner.

LED Status	Indication
LED off	No power supplied to the scanner.
Steady blue light	The scanner is powered on and ready to scan.
One red flash	A barcode has been successfully decoded.
Steady red light	A barcode has been successfully decoded, but the object is not removed from the scan window.
	The scanner is in programming mode.
Flashing blue light	The scanner is in sleep mode.
Steady red/blue light	This indicates the scanner has a motor or laser failure. For motor failure, a periodic beep is sounded. In this case, return the unit for repair.
Flashing red light	The scanner is programmed in USB interface but not connected to a host device.

Sound Indications


Audio feedbacks indicate scanner operation.

Beeps	Indication
One beep	A barcode has been successfully decoded.
Two beeps: low-high	The scanner has entered programming mode.
Two beeps: same tone	Scanner has returned from programming to normal mode.
Four beeps in series	This indicates the scanner passed self-test when powered on and is operating properly.
Continuous tone	This is a failure indication. Return the unit for repair.

Tone and Volume Adjustment

The scanner can be programmed with the Programming Guide to change beeper tone, volume and duration; the tone and volume can also be changed by using the touch control sensors in the front.

Touch Control Sensor

Tone	Volume
	

There are three tones to choose from. Gently touch the note sign and the scanner would change to its next tone. Repeat touching till the desired tone is heard.

On the other hand, there are three levels of volumes to choose from. To change the volume, gently touch the volume sign and the scanner would cycle to its next level. Repeat touching it till the desired level is reached.



Figure 18: Tone & Volume Adjustment



The volume setting is saved in volatile memory. That means the change will be lost when the scanner powers down. On next power-up the scanner would reset to the configured setting. If you wish to keep the changed volume setting, use the Programming Guide to set and save the changes.

Sleep Mode

After the scanner has been inactive for a specific length of time, the laser and the motor would automatically turn off and the scanner would enter the sleep mode. The blue LED would blink as indication.

It takes 2 steps to enter the sleep mode. The first step is the laser switching off after 10 minutes; the second step is the motor switching off after 30 minutes. The time period is programmable.

To wake up the scanner, simply present an object into the IR detection range in front of the scan window or touch the sound indication sensors.




Figure 19: IR detection range



The scanner includes a motion sensor that detects activity in front of the scan window. The detecting distance is about 10cm (3.9 inch) from the scan window while in condition with effectiveness of environment lights. The detecting distance is also programmable.

How to Scan

Scan Volume

The device is an omnidirectional presentation scanner with a 10-direction scan field with a 40-line scan pattern. The scan volume extends approximately 20cm (8") in front of the scan window. Barcode labels can be easily read when presented towards the scanning window. The scanner's scan volume is illustrated as Figure 20.




Figure 20: Scan Volume

Scanning Mode

The scanner can read barcodes in either sweep or presentation mode to accommodate different requirements.

Sweep Mode means moving items through the scan volume. Left to right, right to left, top to bottom, bottom to top, etc. are all okay. Sweep Mode is usually used for high throughput and reduced product handling.




Figure 21: Sweep Mode

Presentation Mode is used where counter top space is at a premium. The product is moved toward the scan window (“presented”) until the barcode is read, then the product is removed.




Figure 22: Presentation Mode

Maintaining the Scanner

The scanner is designed for long-term trouble-free operation and rarely requires any maintenance. Only an occasional cleaning of the scanner window is necessary in order to remove dirt and fingerprints. It can be cleaned while the scanner is running.

When cleaning the scan window, wipe the scan window with a soft lint-free cloth and a non-abrasive cleaner to avoid scratching and damaging the scan window. Do not spray water or cleaning liquid directly into the window.

If the scanner's housing needs cleaning, use a mild cleaning agent that does not contain strong oxidizing chemicals; otherwise the exterior may be damaged.

Trouble Shooting

This section contains information about how to solve problems that you may encounter when operating the scanner. However, before referring to the tips, make sure that the scanner is installed as instructed in this manual and that all cables are properly connected. If the problem remains, please contact your dealer.

Problem	Diagnostic Tips
The scanner is on but cannot read barcodes. The LED is red.	<ul style="list-style-type: none"> ● The scanner window is dirty. Clean the scanner window as described in the Maintenance section. ● The presented barcode type is not enabled. Select the barcode type in the Programming Guide. ● The host disables the scanner. ● The barcode type you presented to the scanner is not supported.
The scanner is on, but the motor is not rotating. A barcode cannot be read. The LED is intermittently flashing blue.	<ul style="list-style-type: none"> ● The scanner has entered the sleep mode. Press the switch on the top of the scanner to wake up the scanner (or use the wake protocol.)
Both the red and blue LED light up (appearing the color purple) and remain flashing.	<ul style="list-style-type: none"> ● The scanner does self test when powered up. The red and blue LED would both light on (appearing the color purple) when the scanner fails the self test. When it happens, disconnect the scanner from its power source immediately and contact your dealer.
The scanner does not accept more than two or three barcode labels.	<ul style="list-style-type: none"> ● There is no proper handshaking with the POS system. Switch on the POS system and check the connection and communication settings. ● The scanner is continuously seeing a barcode. Remove all barcode labels out of the scan volume of the scanner and try again. ● The scanner cannot send the data to the POS system. There is no proper handshaking between the scanner and the host. Make sure that all cables are connected and your POS system is ready to receive data.
A barcode is read by the scanner but not accepted by the POS system.	<ul style="list-style-type: none"> ● The interface cable is not connected to the correct port of your POS system. Refer to the manual of your POS system to locate the serial port. ● The communication settings of the system and scanner do not match. Adjust the settings in order to be equal for both devices. ● The interface cable does not suit your POS system. Contact your dealer for the correct interface cable. ● The software running on the POS system does not support the data format of the barcode label.





Specification

Operational	
Light Source	650nm visible laser diodes (VLD)
MPU	32 bit
Depth of Scan Field	0 – 200 mm (UPC/EAN 100%, PCS=90%)
Scan Pattern	10 directions of scan field
Scan Rate	3600 scans per second (omnidirectional)
Number of Scan Lines	40
Minimum Bar Width	5mil @ PCS 90%
Print Contrast	30% @ UPC/EAN 100%
Indicators (LED)	Two-color LED (blue & red)
Beeper Operation	Programmable tone & volume
System Interfaces	Keyboard wedge, RS-232C, HID USB
Physical	
Height	152 mm
Depth	88 mm
Width	152 mm
Weight	685 g (without cable)
Mounting Option	Integral mounting plate
Cable	Standard 2.0M straight
Power	
Input Voltage	9VDC \pm 10%
Power	4.05 watts
Operating Current	450mA @ 9V (Normal)
Regulatory	
Laser Class	CDRH Class IIa; IEC 60825-1 Class 1
EMC	CE EN55022 B, FCC Part 15 Class B, VCCI, BSMI
Environmental	
Operating Temperature	0°C - 40°C (32°F - 104°F)
Storage Temperature	-20°C - 60°C (-4°C - 140°F)
Humidity	5% ~ 90% RH (no dewing allowed)
Drop Durability	Designed to withstand 1.0M drops
Light Levels	Up to 4000 Lux (fluorescence)

Dimension


Z-6182GT

Unit: mm(inch)




Z-6182

Unit: mm(inch)




Decode Zone

Z-6182GT




Z-6182



Pin Assignment

Device



Host Port

Pin	Host Function		
	Keyboard Wedge	RS-232C	USB
1	N.C.	N.C.	USB Power
2	+9V		
3	KB_CLK		D-
4	PC_CLK	RTS_TTL	N.C.
5	Ground		
6	N.C.	TX_TTL	N.C.
7	N.C.	RX_TTL	N.C.
8	KB_DATA		D+
9	PC_DATA	CTS_TTL	N.C.
10	N.C.	N.C.	N.C.

Auxiliary Port


RS-232 IN Only	
Pin	Function
1	RX_TTL
2	N.C.
3	+5V output, 300mA max.
4	RTS_R
5	Ground
6	TX_R
7	RX_R
8	NC
9	CTS_R
10	TX_TTL

EAS Port (selected model only)

Pin	Function
1	GND
2	ANTENNA+
3	ANTENNA-
4	EAS INPUT
5	EAS OUTPUT
6	SHIELD

Interface Cable


Keyboard Wedge Cable (for PS/2)



The diagram shows a keyboard wedge cable with a PS/2 connector (J1) on the left, labeled with PIN 1 and PIN 10. It has two DIN connectors: P1 (top) and P2 (bottom), each with pins 1 through 6 labeled.

PIN-OUT CONFIGURATION			
P1- MINI DIN (M)		P2- MINI DIN (F)	
Din	FUNCTION	Din	FUNCTION
1	PC Data	1	KB Data
2	N.C.	2	N.C.
3	GND	3	GND
4	+5V	4	+5V
5	PC Clock	5	KB Clock
6	N.C.	6	N.C.


RS-232C Cable – DTE Pin Out



The diagram shows an RS-232C cable with a PS/2 connector (J1) on the left, labeled with PIN 1 and PIN 10. It has a DB-9 connector on the right with pins 1 through 5 labeled.

DB-9 (F)	FUNCTION
2	TX
3	RX
7	CTS
8	RTS
9	+9V
5	GND


RS-232C Cable – DCE Pin Out



The diagram shows an RS-232C cable with a PS/2 connector (J1) on the left, labeled with PIN 1 and PIN 10. It has a DB-9 connector on the right with pins 1 through 5 labeled.

DB-9 (F)	FUNCTION
2	RX
3	TX
7	RTS
8	CTS
9	+9V
5	GND

USB HID / Virtual COM Cable



The diagram shows a USB HID / Virtual COM cable with a PS/2 connector (J1) on the left, labeled with PIN 1 and PIN 10. It has a USB Type A connector on the right with pins #1 and #4 labeled.

USB TYPE A	FUNCTION
1.	VCC
2.	D-
3.	D+
4.	GND